



## INSTALLATION INSTRUCTIONS

### SUITABLE FOR PLAIN AND REBATED LOCKS



1. Refer to door schedule to determine hand of door and lock. Plain kits are reversible, rebate kits are handed.
  2. To rotate the latch, unscrew latch bolt screws and rotate latch bolt head to suit latching direction.
  3. Establish door lock height and mark vertical centreline on door edge.
  4. Align centreline of **edge template** with centreline on door edge and adhere firmly  
*Rebated align right hand or left hand marker lines according to lock handing with centre line marked on door.*
- Mark and accurately drill mortice to desired lock case depth and clean out cavity.

5. Insert lock in mortice and scribe around forend for size of recess. Remove lock from mortice and chisel out recess 3mm for plain forend or 1.6mm for rebated forend. Forend face should fit flush with door edge.

6. Adhere left and right face templates firmly to door surface. Align edge A with bottom of forend recess and the face template lines with the door edge.

*Rebated align Edge B with bottom of forend recess. Left and right face templates must be placed to align with leading edge of door not the lower level of the rebate.*

Mark all hole centres on both sides **except for snib which is marked and drilled inside only**. Drill but to prevent damage to door face do not drill holes right through door from one side.

7. Secure lock to door using two wood screws supplied.

8. Insert cylinder evenly into lock case and secure with cylinder retaining screw through forend.

9. Position striker so that it will accept all bolts when they are in the thrown position. Scribe around striker on doorframe then mortice door frame for striker plate 2mm deep and for the three bolts 15mm deep minimum.


*Rebated striker should be morticed 1.2mm deep and 15mm minimum for the three bolts.*

10. Screw striker plate to door frame with 2 wood screws supplied.

11. Test that lock is operating from both sides with handles and cylinder, prior to closing door.

**Important Note: This template has been downloaded from the Nidus Website and may not be printed to scale.**

Make sure that you check measure the dimensions shown on the template with a ruler or tape measure to ensure that you have printed the template to the correct scale. Nidus Holdings Pty Ltd takes no responsibility for downloaded templates that are not printed to the correct scale.




# OZI - 1 Mortice Lock

Important Note: This template has been downloaded from the Nidus Website and may not be printed to scale.

Make sure that you check measure the dimensions shown on the template with a ruler or tape measure to ensure that you have printed the template to the correct scale. Nidus Holdings Pty Ltd takes no responsibility for downloaded templates that are not printed to the correct scale.

## OZI - 1 Mortice Lock



Line up with other sheet